




## ROOK SERIES PRODUCT MANUAL



| P/N         | NAME  | EXTERIOR COLOR |
|-------------|---|----------------|
| 920-310     | Rook Checkmate                              | Black          |
| 940-010     | Rook MD1 LED Flashlight                     |                |
| 940-310     | Rook MD3 Flashlight                         |                |
| 940-302-470 | Rook 470nm Blue Forensic Light System       |                |
| 940-311     | Rook 380 + 395nm UV Forensic Light System   |                |
| 940-312     | Rook 450 + 470nm Blue Forensic Light System |                |
| 940-365     | Rook 365nm UV Forensic Light System         |                |

### PHYSICAL CHARACTERISTICS

| Model       | Dimensions                               |
|-------------|--|
| 940-302-470 | 5.1 x 1.0 x 1.3 in<br>(129 x 25 x 33 mm) |
| 920-310     | 5.8 x 1.1 x 1.5 in<br>(147 x 28 x 38 mm) |
| 940-010     | 4.9 x 1.0 x 1.3 in<br>(125 x 25 x 33 mm) |
| 940-310     |  |
| 940-311     |  |
| 940-312     |  |
| 940-365     |  |

### BATTERY TYPE & BATTERY LIFE

| Model       | Battery Type            | Battery Life* |
|-------------|-------------------------|---------------|
| 920-310     | (2) CR123s or (1) 18650 | 1 - 3 hours   |
| 940-010     |                         | 3 - 4 hours   |
| 940-310     |                         |               |
| 940-302-470 |                         |               |
| 940-311     |                         |               |
| 940-312     |                         | 5 hours       |
| 940-365     |                         |               |

\*Battery life may vary according to mode selected, battery quality and prevailing ambient conditions.

\*Mixing of new and used or different batteries is not recommended as this could lead to leakage or explosion.

### BATTERY INSTALLATION/REPLACEMENT

1. Each flashlight consists of: Head, Handle, and End Cap
2. To install batteries, first remove the End Cap at the rear of the Main Body.
3. Insert required batteries with the positive terminal (a plus sign) facing the front of the flashlight.
4. After inserting all batteries, replace the End Cap securely.
5. Test the light's performance by activating the Power/Mode Switch below the light head.

NOTE: In the event that the batteries get stuck within the handle, they can be removed by unscrewing the handle from the head. Use a blunt device to push them out.

### OPERATIONAL MODES

FOR P/N 920-310 & 940-010

- ❖ MODE 1: HIGH
- ❖ MODE 2: LOW
- ❖ MODE 3: TURBO-STROBE™

FOR P/N 940-302-470:

- ❖ MODE 1: ON
- ❖ MODE 2: OFF

FOR 940-310:

- ❖ MODE 1: WHITE LIGHT
- ❖ MODE 2: UV LIGHT
- ❖ MODE 3: TURBO-STROBE™

FOR P/N 940-311:

- ❖ MODE 1: ALL LEDS ON
- ❖ MODE 2: UV (380NM)
- ❖ MODE 3: UV (395NM)

FOR P/N 940-312:

- ❖ MODE 1: ALL LEDS ON
- ❖ MODE 2: BLUE (450NM)
- ❖ MODE 3: BLUE (470NM)

FOR P/N 940-365:

- ❖ MODE 1: LOW
- ❖ MODE 2: HIGH

FOR 920-310 & 940-010:

- ❖ HIGH mode: Press the Power/Mode Switch once. From any mode, press twice (once for OFF and once for ON) to get back to HIGH mode.
- ❖ LOW mode: From HIGH mode, press and hold the Power/Mode Switch for 2.5 sec.
- ❖ TURBO-STROBE™ mode: From LOW mode, press and hold the Power/Mode Switch for 2.5 sec. To get back to LOW mode, press and hold the Power/Mode Switch for an additional 2.5 sec.
- ❖ OFF or to EXIT a mode: Press the Power/Mode Switch once.

On all forensic models, modes are similarly changed by depressing and holding the POWER/MODE Switch for 2.5 seconds until desired mode is obtained.

NOTE: The light does not retain the mode in memory. Once you turn the light ON, you will have to reselect the mode you desire.

## PRODUCT DURABILITY



CE-EMC

Meets Requirements of NFPA 1971-8.6 (2013).

## CARE/CLEANING

Your Rook is a professional tool, but regular maintenance and care will maximize performance for you. As needed, wash your Rook using a soft washcloth, clean water and a mild soap. Be sure that the battery pack is SEALED before washing. When done, pat dry with a damp cloth.

## WARNINGS

FoxFury, LLC is not responsible for the incorrect use of any FoxFury Lighting product.

- ❖ Lights are strong enough to cause damage to the human eye.
- ❖ Do not stare into LEDs for long periods of time or from a close range (less than 2 ft).
- ❖ FoxFury, LLC is not responsible for any injury or damage caused during the use of this product.
- ❖ Usage of this product must be supervised by an adult when it is being used by a minor.
- ❖ Any FoxFury product should be operated at speeds safe enough to maneuver around surrounding obstacles.
- ❖ Do not use under the influence of drugs or alcohol.

## UV LIGHT

- Avoid direct eye exposure to UV light.
- Keep out of reach of children.
- The UV LED during operation radiates intense UV light.
- Do not look directly into the UV light during operation, even for a brief period. This can be harmful to the eyes due to the intensity of the UV light.
- When viewing with the UV light, please use UV filtered glasses to avoid damage by the UV light.

## STROBE

FoxFury's Turbo-Strobe™ is purposely designed to induce disorientation. Prolonged viewing may produce vertigo or even vomiting. Note that the frequencies implemented are well below the ones reported to cause photo-induced seizures. As with all products, use common sense while operating.

## LIMITED LIFETIME WARRANTY

FoxFury, LLC ("FoxFury") warrants this product to be free from defects in material for a lifetime of use except for batteries, LEDs, abuse, and normal wear. We will repair or replace this product should we determine it to be defective. This limited lifetime warranty excludes rechargeable batteries, chargers, switches, and electronics, which have a 2-year warranty with proof of purchase.

This limited lifetime warranty is given only to the original end user of the accompanying product. If you purchased a product from someone other than an authorized FoxFury reseller/distributor or if the product was used (including but not limited to demo models, show models or refurbished product by someone other than FoxFury) prior to your purchase, you are not the Original Purchaser and the product that you purchased is not covered by this warranty. This limited warranty is VOID if this Product has been altered or modified in any way (including but not limited to attempted warranty repair without authorization from FoxFury and/or alteration/removal of the serial number). To expedite warranty concerns, we encourage the end user to register their FoxFury Product at [www.foxfury.com/pages/warranty-registration](http://www.foxfury.com/pages/warranty-registration).

THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW.

You may have other specific legal rights which vary by jurisdiction. Go to [www.foxfury.com/pages/warranty](http://www.foxfury.com/pages/warranty) for a complete copy of the warranty. Retain your receipt for proof of purchase.

## CONTACT FOXFURY

FoxFury, LLC  
Oceanside, CA 92056 USA  
**Toll-Free:** 844-FOXFURY  
**Tel:** 760.945.4231  
**Fax:** 760.433.3650  
**Email:** [service@FoxFury.com](mailto:service@FoxFury.com)  
**Web:** [FoxFury.com](http://FoxFury.com)

All FoxFury products are designed in Oceanside, CA. All FoxFury products are manufactured with the highest quality USA and foreign parts. Products are assembled in either FoxFury's controlled plant in Asia or the USA, under strict quality control.