





NOMAD® TRANSFORMER® EXTENSION (2.5FT) (P/N 85-600)

OPTION 1: FULLY DEPLOYING THE NOMAD® WITH THE EXTENSION



NOMAD® TRANSFORMER®
WITH EXTENSION
(EXPLODED VIEW)

- 1 Unscrew all five (5) Caps from the four (4) different parts of the Nomad® Transformer® (Light Head, Tripo-Scope®, Power Pack, and Extension).
- 2 Once all Caps are removed, place the Tripo-Scope® onto the Power Pack (male end), line up the I, II, and III marks. Once aligned, tighten the Locking Ring to secure the Tripo-Scope® to the Power Pack. The Folding Tripo-Scope® Legs are now ready to deploy. Unfold each Tripo-Scope® Leg and make sure they are locked in place.
- 3 Open the Protective Light Cap to raise the Tripo-Scope® Poles slightly (do NOT raise the poles all the way, as the Light Head and Extension still needs to be installed). Install the Extension to the Tripo-Scope® Pole. Line up the I, II, and III marks then tighten the Locking Ring to secure the Extension to the Tripo-Scope® Pole. Place the Light Head on top of the Extension. Line up the I, II, and III marks then tighten the Locking Ring to secure the Light Head to the Extension.

❖ Keep the Light Panels as they are for a 360 configuration or, open the Light Panels for a Directional configuration. Then, based on preference or need, adjust the Sliding Diffuser Lens to either Area or Spot lighting.


❖ Adjust the angle and swivel position of the Light Head by loosening the Tilt Adjustment Knob to the desired orientation and then re-tighten.

- 4 Elevate the Light Head to desired height by raising the Tripo-Scope® Poles. Tighten the Tripo-Scope® Tightening Rings (clockwise) to hold the poles at desired height.

❖ **IMPORTANT!** To reposition, loosen the Tightening Rings, bring the Tripo-Scope® Poles down again, and turn the Light Head OR, physically pick up and move the position of the whole Nomad®. Turning the Tripo-Scope® Poles against each other can cause permanent damage.

WARNING! The Nomad® Transformer® is heavy once fully assembled. If you need to move it once it is deployed, use a Team Lift approach with at least two people, OR disassemble and then reassemble at new location.

OPTION 2: INSTALLING THE EXTENSION WITH NO TRIPO-SCOPE®



Begin with the Light Head, Power Pack, and the Transformer® Extension.

- 1 Remove all four (4) Caps from the Light Head, Power Pack, and the Transformer® Extension. Then place the Power Pack on level ground.
- 2 Install the Transformer® Extension onto the Power Pack and line up the I, II, and III marks. Once aligned with the marks, tighten the Locking Ring on the Extension. Then, install the Light Head onto the opposite end of the Extension and align the marks (I, II, III). Then, tighten the Locking Ring on the Light Head to secure both pieces together.

⚡ Once completely installed, press the Power/Mode Switch to turn the Nomad® ON.

WARRANTY

LIMITED LIFETIME WARRANTY

FoxFury, LLC ("FoxFury") warrants this product to be free from defects in material for a lifetime of use except for batteries, LEDs, abuse, and normal wear. We will repair or replace this product should we determine it to be defective. This limited lifetime warranty excludes rechargeable batteries, chargers, switches, and electronics, which have a 2-year warranty with proof of purchase.

This limited lifetime warranty is given only to the original end user of the accompanying product. If you purchased a product from someone other than an authorized FoxFury reseller/distributor or if the product was used, (including but not limited to demo models, show models or refurbished product by someone other than FoxFury) prior to your purchase, you are not the Original Purchaser and the product that you purchased is not covered by this warranty. This limited warranty is VOID if this Product has been altered or modified in any way (including but not limited to attempted warranty repair without authorization from FoxFury and/or alteration/removal of the serial number). To expedite warranty concerns, we encourage the end user to register their FoxFury Product at www.foxfury.com/pages/warranty-registration.

THIS IS THE ONLY WARRANTY,

EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW.

You may have other specific legal rights which vary by jurisdiction. Go to www.foxfury.com/pages/warranty for a complete copy of the warranty. Retain your receipt for proof of purchase.

CONTACT FOXFURY

FoxFury, LLC
Oceanside, CA 92056 USA
Toll-Free: 844-FOXFURY
Tel: 760.945.4231
Fax: 760.433.3650
Email: service@foxfury.com
Web: [FoxFury.com](http://www.foxfury.com)

All FoxFury products are designed in Oceanside, CA. All FoxFury products are manufactured with the highest quality USA and foreign parts. Products are assembled in either FoxFury's controlled plant in Asia or the USA, under strict quality control.