


# QUICK START GUIDE

# NOMAD<sup>®</sup> NOW, N32 & N56 BATTERY REPLACEMENT


P/N 600-200-400 (FOR P/N 200-400-100, 200-400-102, 200-4N32 & 200-4P56)

Nomad<sup>®</sup> Replacement Battery is packaged in a black Life Light casing for safe air transport. Once you receive the Nomad<sup>®</sup> Replacement Battery, remove the Battery Pack from the case for storage if Battery is not replaced right away.

#### HOW TO REMOVE THE NOMAD BATTERY TUBES FROM CASE




- 2 Simultaneously, unscrew the Hex Nut until it comes loose, using a 5.5 mm socket or wrench.
- 3 Repeat step 1 and 2 three more times to remove the remaining Hex Nuts.
- 4 Remove the black cover.
- 5 Detach the Battery from the case by unclipping the Connector.
- 6 Remove the Battery Pack.




# REPLACING THE NOMAD® BATTERY PACK

FOR NOMAD® NOW, N32, AND N56 APPROXIMATELY 4 MINS




Make sure the Nomad<sup>®</sup> is turned OFF before starting.





2 Use a Phillips Head screwdriver to unscrew and remove the eight (8) screws. Then, remove the rear panel.





4 Pull the Battery Pack out of the Nomad<sup>®</sup> Body. Then, detach it from the light by unclipping the Connector.

FOR RE-INSTALLATION: Repeat steps 1-4 in reverse order. Remember to test the light's performance by activating the Power/Mode Switch.

#### LIMITED LIFETIME WARRANTY

FoxFury, LLC ("FoxFury") warrants this product to be free from defects in material for a lifetime of use except for batteries, LEDs, abuse, and normal wear. Mechanical components subjected to constant deformation or action, like springs and switches, and electronic components including chargers and LEDs are warranted for a period of two years from the time of purchase. FoxFury will repair or replace a product should it be determined defective.

Rechargeable batteries are consumable items, and carry a prorated 2 year warranty. Example: If a problem arises after one year of use, only 50% of the replacement cost will be charged, as long as the batteries are verified to have been charged, stored, and used in accordance with required practices.

This limited lifetime warranty is given only to the original end user of the accompanying product. If you purchased a product from someone other than an authorized FoxFury reseller/distributor or if the product was used. (including but not limited to demo models, show models or refurbished product by someone other than FoxFury) prior to your purchase, you are not the Original Purchaser and the product that you purchased is not covered by this warranty. This limited warranty is VOID if this Product has been altered or modified in any way (including but not limited to attempted warranty

repair without authorization from Foxfury and/or alteration/removal of the serial number). To expedite warranty concerns, we encourage the end user to register their FoxFury Product at www.foxfury.com/pages/ warranty-registration.

THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW.

You may have other specific legal rights which vary by jurisdiction. Go to www.foxfury.com/pages/warranty for a complete copy of the warranty. Retain your receipt for proof of purchase.

### CONTACT FOXFURY

FoxFury, LLC Oceanside, CA 92056 USA Tel: 760.945.4231 Email: service@FoxFury.com Web: FoxFury.com

All FoxFury products are designed in Oceanside, CA. All FoxFury products are manufactured with the highest quality USA and foreign parts. Products are assembled in either FoxFury's controlled plant in Asia or the USA, under strict quality control.

## CALIFORNIA PROPOSITION 65

This product can expose you to chemicals including Lead and DEHP, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www. P65Warnings.ca.gov.