



EXOLANDER[®] SYSTEMS AUTEL EVO II ENTERPRISE

700-XLS-II E | 700-XSS-II E

PRODUCT MANUAL

TABLE OF CONTENTS

EXOLANDER® SYSTEMS	3
EXOLANDER® Landing System	
Reference Guide	4
Physical Characteristics	5
Installation	5 - 7
D100 DRONE SPOTLIGHT®	
Reference Guide	8
Physical Characteristics	9
Battery	10
Operational Modes	10
Installation	11-12
CARE/CLEANING	13
WARNINGS/WARRANTY	13-14
CONTACT FOXFURY	14

EXOLANDER® SYSTEMS

	EVO II Enterprise Saddle Mount®	EXOLANDER®	Landing Skids, set of 2	D100 Drone Spotlight®
 EXOLANDER® Landing System for EVO II Enterprise P/N 700-XLS-IIIE				- - -
 EXOLANDER® Spotlight System for EVO II Enterprise P/N 700-XSS-IIIE				


EXOLANDER® LANDING SYSTEM REFERENCE GUIDE

EVO II ENTERPRISE SADDLE MOUNT®




SNAP LOCK
(7 EA)


EXOLANDER® HALF



EXOLANDER® ASSEMBLED



LANDING SKIDS



INCLUDED

- ❖ EVO II Enterprise Saddle Mount®
- ❖ EXOLANDER®
- ❖ Landing Skid, set of 2

PHYSICAL CHARACTERISTICS

	DIMENSIONS	WEIGHT*
EVO II Enterprise Saddle Mount®	3.29 x 2.63 x 3.5 in (83.5 x 66.8 x 88.9 mm)	1.29 oz (36.5 g)
EXOLANDER®, assembled	6.8 x 6.5 x 4.8 in (173.2 x 163.8 x 123 mm)	4.05 oz (114.7 g)
Landing Skid	8.67 x 0.97 x 0.6 in (220 x 24.7 x 15.2 mm)	0.45 oz (12.8 g) per skid

*Total weight of 700-XLS-II-E system is 6.24 oz (176.8 g).


WARNINGS

- ⚠ It is the responsibility of drone/UAV users to follow the FAA and global laws and regulations and/or the laws and regulations applicable to the flight location.
- ⚠ While using any FoxFury product, please operate at safe speeds.

EXOLANDER® LANDING SYSTEM INSTALLATION


1 Install Saddle Mount® on EVO II Enterprise.

- Slide the Saddle Mount® on EVO II Enterprise and make sure that the two extensions fit behind the front arms of the EVO II Enterprise and press down.



2 Install EXOLANDER® on Saddle Mount®.


1. Place EVO II Enterprise with Saddle Mount® upside down on a flat surface.
2. Align the EXOLANDER® Half with Snap Lock locations on Saddle Mount® and slide in the EXOLANDER® Half at an angle as shown below. Make sure the foot is facing away from the center of the drone. Tilt the EXOLANDER® Half as shown.



3. Install the other EXOLANDER® Half in the open Saddle Snap Lock locations. Bring the units together and align the Pin into the Hole on each side.



4. Align Locking Knob & Screw and Thread Locking Nut Insert on each side.



5. Tighten each screw until the units are mated.



6. The EXOLANDER® installation is now complete.



7. To install the Landing Skid, align each Tab on Landing Skid with each Slot on the EXOLANDER® Landing Foot. Press and snap Landing Skid on.

WARNING:

Manually test the EXOLANDER® Landing System by wiggling it and making sure nothing is loose. Note that a small amount of movement between the structure and the UAV has been created, at the request of Autel, to eliminate adding unnecessary forces to the vehicle's structure.

NOTE:

Do not pull/spread the Saddle during installation. The Saddle is intended to be pushed into place.

NOTE:

Before our accessories are made available, they are tested internally and verified externally by a minimum of 2 professional users. We have experienced multiple cases of UAS (drone) mechanical modifications from manufacturers within the same P/N and revision, and without providing warnings or product updates. If there is a fit problem, please contact our customer service department at <https://www.foxfury.com/contact/>

D100 DRONE SPOTLIGHT[®]

REFERENCE GUIDE





D100 DRONE SPOTLIGHT[®]



BACK VIEW



INCLUDED






-  D100 Drone Spotlight®
-  Mounting Knob (2 ea)
-  18650 Lithium-Ion Battery (2 ea)
-  XTAR Battery Charger

PHYSICAL CHARACTERISTICS

DIMENSIONS	3.46 x 2.01 x 2.44 in (88 x 51 x 62 mm)
WEIGHT	8.92 oz (253 g) 12.23 oz (346.6 g) with provided 18650 batteries

*Total weight of 700-XSS-II-E system is 18.47 oz (523.4 g).

WARNINGS


-  Please fully charge the provided 18650 batteries before using the D100® for the first time.
-  Do not stare into the LEDs for long periods of time or from close range (less than 2 ft / 0.6 m)
-  While using any FoxFury product, please operate at safe speeds.
-  It is the responsibility of drone/UAV users to follow the FAA and global laws and regulations and/or the laws and regulations applicable to the flight location.
-  The D100® will become hot to touch after 20 min of continuous use. Please handle carefully by avoiding contact with the metal heatsink.

BATTERY

- ❖ D100® requires two (2) 18650 batteries.
- ❖ Mixing of new and used, or different brand batteries, is not recommended as this could lead to leakage or explosion.

BATTERY INSTALLATION AND REPLACEMENT

- 1 Slide the battery cover open and insert the battery according to the plus (+) and minus (-) symbol located inside of the battery compartment.
- 2 Once batteries are installed, test the light's performance by activating the Power/Mode Switch. Slide the battery cover back on.



CHARGING BATTERY

Refer to the instruction manual provided with the XTAR Battery Charger.

OPERATIONAL MODES

- ❖ Press and hold Power/Mode Button to turn the light ON.
- ❖ Press Power/Mode Button again to change the mode to STROBE.
- ❖ Press Power/Mode Button again to turn the light OFF.

MODE	LUMENS	BATTERY LIFE
ON	2,300	70 minutes
TURBO-STROBE	2,300	140 minutes

D100[®] INSTALLATION

ITEMS REQUIRED

❖ EXOLANDER[®] Landing System

- 1 Install EXOLANDER[®] Landing System on the drone. Reference p.5 - 7.
- 2 Install D100[®] on EXOLANDER[®] Landing System.
 1. Insert each Mounting Knob in the D100[®] Mounting Hole of the forward-facing section of EXOLANDER[®].



2. Align the Mounting Knobs with the 1/4-20 threaded screw holes on D100[®] to install D100[®] on EXOLANDER[®]. Make sure the switch cover faces the right side (facing the unit). Note that the curved rear edge should be on the top.



3. Tilt D100® to access the Switch and turn it on to desired mode.



4. Adjust the tilt of D100® to desired angle and tighten the Mounting Knobs.



WARRANTY AND OTHER INFORMATION

PRODUCT DURABILITY



Any FoxFury product should be operated at speeds safe enough to maneuver around surrounding obstacles.

Do not use under the influence of drugs or alcohol.

CARE/CLEANING

Your FoxFury product is a professional tool. Regular maintenance and care of your light will maximize performance for you. As needed, clean your FoxFury product using a damp soft washcloth. Do not immerse.

ACCESSORIES

- Rechargeable 18650 Li-Ion Battery, P/N 70-18650T
- Battery Charger, 600-155

WARNINGS

FoxFury, LLC is not responsible for the incorrect use of any FoxFury Lighting product.

- When used for extended periods of time the D100® will become HOT to the touch. Please use care when operating.
- Lights are strong enough to cause damage to the human eye.
- Do not stare into LEDs for long periods of time or from a close range (less than 2 ft / 0.6 m).
- FoxFury, LLC is not responsible for any injury or damage caused during the use of this product.
- Usage of this product must be supervised by an adult when it is being used by a minor.

ONE YEAR WARRANTY

FoxFury, LLC ("FoxFury") warrants this product to be free from defects in material for one year after purchase. Li-Ion batteries have a one year pro-rated or 500 re-charge cycle pro-rated warranty, whichever the user reaches first.

This warranty is given only to the original end user of the accompanying product. If you purchased a product from someone other than an authorized FoxFury reseller/distributor or if the product was used, (including but not limited to demo models, show models or refurbished product by someone other than FoxFury) prior to your purchase, you are not the Original Purchaser and the product that you purchased is not covered by this warranty. This warranty is VOID if this Product has been altered or modified in any way (including but not limited to attempted warranty repair without authorization from FoxFury and/or alteration/removal of the serial number). To expedite warranty concerns, we encourage the end user to register their FoxFury Product at www.foxfury.com/pages/warranty-registration.

THIS IS THE ONLY WARRANTY,
EXPRESSED OR IMPLIED,
INCLUDING ANY WARRANTY OF
MERCHANTABILITY OR FITNESS
FOR A PARTICULAR PURPOSE.
INCIDENTAL, CONSEQUENTIAL
OR SPECIAL DAMAGES ARE
EXPRESSLY DISCLAIMED EXCEPT
WHERE SUCH LIMITATION IS
PROHIBITED BY LAW.

You may have other specific legal
rights which vary by jurisdiction. Go to
www.foxfury.com/pages/warranty for a
complete copy of the warranty. Retain
your receipt for proof of purchase.

CONTACT FOXFURY

FoxFury, LLC
Oceanside, CA 92056 USA
Tel: 760.945.4231
Email: service@FoxFury.com
Web: FoxFury.com

All FoxFury products are designed in
Oceanside, CA. All FoxFury products
are manufactured with the highest
quality USA and foreign parts.
Products are assembled in either
FoxFury's controlled plant in Asia or the
USA, under strict quality control.

CALIFORNIA PROPOSITION 65

This product can expose you to
chemicals including Lead and DEHP,
which are known to the State of
California to cause cancer and birth
defects or other reproductive harm.

For more information go to
www.P65Warnings.ca.gov.

